



# SurfGate User Manual (NTD83X/Gateway)

NTD83X-UserQ



SyncWave Inc.

# Table of Contents

|                                                                |    |
|----------------------------------------------------------------|----|
| Table of Contents .....                                        | 2  |
| 1. Safety Instructions .....                                   | 4  |
| 2. Device Introductions .....                                  | 5  |
| 3. Device Specifications .....                                 | 9  |
| 4. Pre-Boot Preparation .....                                  | 12 |
| 5. Initial Setup (WebUI Login) .....                           | 13 |
| 6. LTE (Cellular Network) .....                                | 14 |
| 7. Ethernet Management .....                                   | 15 |
| 1. When using Ethernet as LAN .....                            | 15 |
| 2. When using Ethernet as WAN .....                            | 17 |
| 8. Wireless LAN .....                                          | 19 |
| 1. Wifi STA (Wireless Client Mode) .....                       | 19 |
| 2. WLAN Basic Settings (Access Point Mode) .....               | 20 |
| 3. Wireless MAC Filter .....                                   | 21 |
| 9. VPN .....                                                   | 22 |
| 1. SSTP .....                                                  | 22 |
| 2. IPSec .....                                                 | 24 |
| 10. RS485/232 .....                                            | 26 |
| 1. Modbus RTU connection .....                                 | 26 |
| 2. Connectivity Device Settings (Pre-installed Devices) .....  | 27 |
| 2-1. Pre-installed devices setting .....                       | 27 |
| 2-2. List of Pre-installed devices .....                       | 27 |
| 2-3. Checking data of pre-installed devices .....              | 27 |
| 2-4. CSV output of pre-installed devices .....                 | 27 |
| 3. Connected device settings (Non Pre-installed Devices) ..... | 28 |
| 11. EnOcean .....                                              | 30 |
| 1. EnOcean Device Manager screen description .....             | 30 |

|                                                 |    |
|-------------------------------------------------|----|
| 2. Register from the Register Device List ..... | 31 |
| 3. Register from Manually Register Device ..... | 32 |
| 4. Register through Teach-in.....               | 33 |
| 5. EnOcean Equipment Screen Description.....    | 34 |
| 6. Register the sensor .....                    | 34 |
| 7. Removing the sensor.....                     | 35 |
| 8. List of supported EEPs.....                  | 36 |
| 9. List of Supported GPs.....                   | 38 |
| 12. Modbus TCP .....                            | 39 |
| 1. Modbus TCP connection.....                   | 39 |
| 2. Modbus Address Map (EnOcean) .....           | 40 |
| 3. Modbus Address Map (Modbus RTU).....         | 40 |
| 13. FTP/SFTP .....                              | 42 |
| 1. FTP Upload.....                              | 42 |
| 2. FTP Gather .....                             | 43 |
| 3. Un_upload List .....                         | 44 |
| 14. MQTT.....                                   | 45 |
| 15. Cloud Service.....                          | 48 |
| 1. Connect to AWS .....                         | 48 |
| 2. Connect to Azure .....                       | 49 |
| 16. Software Updates .....                      | 51 |
| 17. Network Interface .....                     | 52 |
| 18. Revision History .....                      | 53 |
| 19. Information.....                            | 55 |

# 1. Safety Instructions

This chapter describes safety precautions.

---


To use this product safely, please follow instructions below:

- Please adhere to the guidelines provided in this user manual when using the product.
- Do not store, install, or use the product in the following environments:
  - Areas highly affected by vibration and shock.
  - Unstable locations.
  - Places exposed to outdoor elements such as direct sunlight, wind, rain, and water.
  - Environments with temperatures and humidity levels outside the specified range.
  - Locations where humidity fluctuates drastically, leading to condensation or freezing risks.
  - Areas influenced by electric and magnetic fields.
  - Sites prone to strong high-frequency noise, surges, corrosive gases, and dissolved liquids.
- Ensure that the area around the product is not blocked to allow for proper heat dissipation.
- Avoid installing the product near heat-generating equipment.
- Never throw the product into a fire or expose it to excessive heat.
- Do not attempt to disassemble, modify, or repair the product.
- When mounting the product on a DIN rail, ensure that all screws are securely tightened.
- Cease using the product immediately if you notice any abnormal noise, odor, smoke, or excessive heat generation.
- Use caution when installing or removing SIM cards or SD cards; apply only the necessary force.
- Dispose of the device appropriately following local government regulations.

## 2. Device Instructions


This chapter describes the names and roles of each part.

< Right side / Front >




|                        |                                                               |
|------------------------|---------------------------------------------------------------|
| ① LTE antenna port     | Connection terminals for LTE antennas                         |
| ② WIFI Antenna Port    | Connection terminals for wireless LAN antennas                |
| ③ Shared Antenna Ports | Connection terminals for LTE (sub) and EnOcean antennas, etc. |
| ④ RS232/RS485 port     | Connection terminals for RS232 and RS485                      |
| ⑤ DC power port        | Connection terminals for DC power cables                      |
| ⑥ SD Card slot         | Slot to insert Micro SD Card                                  |

< Left side / Back side >




|                    |                                                          |
|--------------------|----------------------------------------------------------|
| ⑦ USB-C port       | Terminal for connecting USB-Type-C                       |
| ⑧ Mounting bracket | Metal fittings for attaching to a wall, etc. (removable) |
| ⑨ DIN rail bracket | Metal fittings for mounting on the DIN rail (removable)  |

< Top >



|                |                                                  |
|----------------|--------------------------------------------------|
| ⑩ USB-A port   | Terminal for connecting a USB device (for Debug) |
| ⑪ SIM Slot     | Slot to insert Micro SIM (3FF)                   |
| ⑫ Reset button | Reset factory default button (press 10 seconds)  |

< Bottom >



|                 |                                                                |
|-----------------|----------------------------------------------------------------|
| ⑬ Ethernet port | Terminals for connecting 100BASE-TX Ethernet cables            |
| ⑭ DC power port | Terminal for connecting the included AC adapter (12V standard) |

< Attached Antenna >



|                           |                                                          |
|---------------------------|----------------------------------------------------------|
| ⑮ General-purpose antenna | Antennas for LTE, WIFI                                   |
| ⑯ Sub-GHz Antenna         | Sub-GHz band (920 MHz) antennas such as EnOcean receiver |



## 3. Device Specifications

This chapter describes the product specifications.

### Basic Hardware

| item  | criterion                                            |
|-------|------------------------------------------------------|
| CPU   | Dual Core; ARM Cortex-A7 up to 1.2GHz; ARM Cortex-R5 |
| RAM   | 128MB DDR2                                           |
| Flash | 256MB Nandflash                                      |

### Cellular Interface

| item               | criterion      |
|--------------------|----------------|
| 4G                 | LTE Category 4 |
| Number of antennas | 2              |
| Connector          | SMA            |
| SIM                | Micro SIM ×1   |
| LTE Frequencies    | 1,3,8,18,19,41 |

### Serial Interface

| item           | criterion                                                                           |
|----------------|-------------------------------------------------------------------------------------|
| Type           | RS485×1 or RS232 ×1                                                                 |
| Connector      | 5-pin Data+ (A), Data- (B), TXD, RXD, GND; 3.5mm terminal block<br>3-pin VCC GND PE |
| ESD protection | Class 4                                                                             |
| Baud rate      | 2400 bps to 115200 bps                                                              |

### Ethernet Interface

| item                        | criterion                           |
|-----------------------------|-------------------------------------|
| Number of ports             | 10/100/the 1000 Mbps ×1, LAN or WAN |
| Magnet isolation protection | 1.5KV                               |

### Wireless Interface

| item               | criterion                                              |
|--------------------|--------------------------------------------------------|
| Number of antennas | 1                                                      |
| Connector          | SMA                                                    |
| Standards          | 802.11 b/g/n, 1 x 1 MIMO, supports AP and Client modes |
| Frequency bands    | 2.412 – 2.484 GHz                                      |

### EnOcean Interface (Optional)

| item                    | criterion                       |
|-------------------------|---------------------------------|
| Number of antennas      | 1                               |
| Standards               | 928MHz (Japan); 868Mhz (Europe) |
| Connector               | SMA                             |
| Sensitivity             | -95 dBm                         |
| Modulation              | FSK                             |
| Data rate               | 125Kbps                         |
| MAX Registrable Sensors | 100                             |
| MAX Monitorable Sensors | 24                              |

### Others

| item           | criterion                                                                        |
|----------------|----------------------------------------------------------------------------------|
| SD             | Micro SD (Max 128GB)                                                             |
| Reset button   | 1                                                                                |
| USB            | USB 2.0 (host) × 1, Type A, 5V 500mA                                             |
| LED indicators | left: power, Ethernet, WIFI, Link-K (socket connected)<br>right: signal strength |
| Watchdog       | built-in hardware watchdog                                                       |

### Software

| item                 | criterion                                                                                                   |
|----------------------|-------------------------------------------------------------------------------------------------------------|
| OS                   | Linux OpenWRT                                                                                               |
| Network Protocols    | PPP, PPPoE, TCP, UDP, MQTT(s), DHCP, ICMP, NAT, HTTP(s), DNS, NTP, SMTP, ARP, NTP, SMTP, Telnet, DDNS, etc. |
| Industrial Protocols | Modbus RTU, Modbus TCP, BACnet IP※                                                                          |
| VPN                  | OpenVPN, SSTP, IPsec                                                                                        |
| Firewall             | DMZ, anti-DoS, Filtering (IP/Domain name/MAC address), Port Mapping, Access Control                         |
| Remote management    | SurfView remote management system, WebUI, SSH                                                               |

### Cloud Connection

| item  | criterion              |
|-------|------------------------|
| Cloud | AWS; Azure; Cumulocity |

### Power Supply and Consumption

| item                | criterion                    |
|---------------------|------------------------------|
| 12V Adaptor Supply  | DC-Jack; 3-pin terminator    |
| Wired Power Supply  | 3-pin terminator (+, -, GND) |
| Input Voltage Range | 9 ~ 36V DC                   |

|                   |                                  |
|-------------------|----------------------------------|
| Power consumption | Idle: 1W<br>Data link: 5W (peak) |
|-------------------|----------------------------------|

### Physical Characteristics

| item                  | criterion                                         |
|-----------------------|---------------------------------------------------|
| Dimensions            | 97×83×27mm                                        |
| Weight                | 298g                                              |
| Housing               | Metal                                             |
| Installations         | Desktop, wall mounting and 35mm DIN rail mounting |
| Operating temperature | -20 ~ +70 °C                                      |
| Storage temperature   | -20 ~ +80 °C                                      |

### Certification

| item        | criterion  |
|-------------|------------|
| Europe      | CE         |
| Japan       | Telec/Jate |
| Environment | RoHs       |

### Regulatory

| item      | criterion                                                                                                                                           |
|-----------|-----------------------------------------------------------------------------------------------------------------------------------------------------|
| EMI       | EN55032 CE, Class B                                                                                                                                 |
| EMS       | IEC61000-4-2 ESD, Level 4<br>IEC61000-4-4 EFT, Class B<br>IEC61000-4-5 SURGE, Level 4<br>IEC61000-4-6 CS, Class A<br>IEC61000-4-11 DIP, Class C298g |
| Vibration | IEC60068-2-6                                                                                                                                        |
| Shock     | IEC60068-2-27                                                                                                                                       |

## 4. Pre-Boot Preparation

This chapter describes the preparations before startup.

---

- Install the Antenna

When using the wireless function, attach an antenna to each port corresponding to the intended function. Ensure that the antenna is firmly attached to prevent any rotation, as this can affect antenna sensitivity.

- Insert SIM card

Insert the SIM card following the orientation indicated on the product label. Pay close attention to the direction in which the SIM is inserted. Inserting it forcibly may result in difficulty removing it. Ensure the device is powered off before inserting the SIM; otherwise, it will not be recognized. If you do not intend to use the cellular network, there's no need to insert the SIM card.

Insert the SIM card in the orientation indicated on the product label.

- Insert SD card

Insert the SD card following the orientation indicated on the product label. Take care to align the insertion direction properly. Forcing the SD card may make it difficult to remove. Ensure the device is powered off before inserting the SD card to prevent recognition issues. If you do not plan to use an SD card, there's no need to insert it.

- Plug the AC adapter


Plug the included AC adapter to the power terminal of this product and plug it into an electrical outlet.

- When plugged into an outlet, the power is turned on automatically.
- Remember to unplug the adapter from the outlet when finished to turn off the power.
- Please note that as a countermeasure against power outages, the product may continue to run for a short while after the power is turned off.

## 5. Initial Setup (WebUI Login)

This chapter describes the procedure for logging in to the WebUI.

1. Insert SIM Card.
  - \* Pay attention to the direction when inserting the SIM card.
  - \* Ensure the power is off before inserting the SIM card, as it will not be recognized if inserted while the power is on.
  - \* If you do not intend to use the cellular network, there's no need to insert the SIM card.
2. Plug the AC adapter that came with this product into an electrical outlet.
3. Start your computer.
4. Connect the USB-C port of this product to the USB port of the computer with a USB cable.
5. Launch a web browser on your computer.
6. Enter the following URL in the address bar.  
192.168.1.1
7. When the login screen is displayed, enter the following login information.



>Username: admin

>Password: admin


\*It may take some time to display immediately after starting this product, so if you cannot connect, wait for a while and then connect again.

8. The login is completed and the dashboard is displayed.


## 6. LTE (Cellular Network)

This chapter describes the LTE connection procedure.

1. Select [Internet] from the main menu.
2. Select [APN Management] from the side menu.



3. Click [New APN Profile] to set the APN information of the inserted SIM.



4. Select [OK].
5. Select the APN Profile you created from the APN drop-down menu .




6. Click [Save].

# 7. Ethernet Management

This chapter describes the Ethernet Management procedure.

## 1. When using Ethernet as LAN


1. Select [Internet] from the main menu.
2. Select [Ethernet Management] from the side menu.
3. Click [Edit] from the Ethernet Management.



The screenshot shows the 'Internet' management page. On the left is a sidebar menu with options: Internet Connection, APN Management, LTE WAN, Ethernet Management (highlighted with a red box), and DHCP Settings. The main content area is titled 'Ethernet Management' and contains a table with the following data:

| Ethernet Port | LAN/WAN Mode | Ethernet Mode | IP Address  | Subnet Mask   | Operation            |
|---------------|--------------|---------------|-------------|---------------|----------------------|
| 1             | LAN          | DHCP_SERVER   | 192.168.1.1 | 255.255.255.0 | <a href="#">Edit</a> |

4. Enter the following from the Ethernet Management.



The screenshot shows the configuration form for Ethernet Management. It includes the following fields and options:

- Ethernet Port:** 1
- LAN/WAN Mode:**  LAN  WAN
- Ethernet Mode:**  DHCP\_SERVER  Static
- Gateway IP:** 192.168.1.1
- Subnet Mask:** 255.255.255.0

Below the mode selection, there is a note: "If needed, click [here](#) to configure DHCP settings". At the bottom right, there is an 'OK' button.

-LAN/WAN Mode: In the case of LAN

-Ethernet Mode: DHCP\_SERVER

The connected device is automatically assigned an IP address by DHCP.

-Gateway IP : DHCP Default Gateway in Setting IP (cannot be changed)

-Subnet Mask: Subnet Mask of DHCP Setting (cannot be changed)

-Ethernet Mode: Static case

Any IP address and subnet mask can be assigned to the Ethernet port. It is not possible to assign the same settings as the segments assigned by DHCP Settings.

-LAN IP: Any IP address

- Subnet Mask: Arbitrary Subnet Mask


5. Click the OK button.

\*For more information about interfaces, see chapter 17 Network Interface.




## 2. When using Ethernet as WAN

1. Select [Internet] from the main menu.
2. Select [Ethernet Management] from the side menu.
3. Click [Edit] from the Ethernet Management.



4. Enter the following from the Ethernet Management.



-LAN/WAN Mode: In the case of WAN

-Ethernet Mode : DHCP\_CLIENT

An IP address can be automatically assigned by DHCP from the opposing device.

-IP Address: Auto-assigned/cannot be changed

-Subnet Mask: Auto-assigned/cannot be changed

-Ethernet Mode : Static

Assign an arbitrary IP address and Subnet Mask to the Ethernet port.

-WAN IP: Any IP address

-Subnet Mask: Any Subnet Mask

-Gateway IP: Gateway IP address of the network to be connected

-DNS1 (optional): Any DNS server address (primary)

-DNS2 (optional): Any DNS server address (secondary)

5. Click the OK button.

\*For more information about interfaces, see chapter 17 Network Interface.

## 8. Wireless LAN

This chapter describes the procedure for setting up a wireless LAN.

### 1. Wifi STA (Wireless Client Mode)

1. Log in to the WebUI and select [Wireless] from the main menu.
2. Select [Wifi STA] from the side menu.
3. Enter the following from the Wifi STA.

The screenshot displays the 'Wifi STA' configuration interface. At the top, there is a navigation bar with tabs for 'IoT', 'Dashboard', 'Internet', 'Wireless', and 'System'. Below this, a sidebar on the left contains 'Wifi STA', 'WLAN Basic Settings', 'WLAN Advanced Settings', and 'Wireless MAC Filter'. The main content area is titled 'Wifi STA' and includes a 'Wifi STA Status' section with radio buttons for 'Enabled' and 'Disabled' (selected). Below this is an 'Information' section with fields for 'SSID', 'Security Type' (set to 'WPA2-PSK'), and 'Wi-Fi Password'. A 'Show Password' checkbox is located below the password field. An 'OK' button is positioned at the bottom right of the configuration area.

-Wifi STA Status: Enabled / Disabled

-SSID: SSID of the connection destination

- Security Type: Security Type of the connection destination - Wi-Fi Password: Wi-Fi Password of the connected Access Point

4. Select [OK].

## 2. WLAN Basic Settings (Access Point Mode)

1. Log in to the WebUI and select [Wireless] from the main menu.
2. Select WLAN Basic Settings from the side menu.
3. Enter the following from the WLAN Basic Settings.

**WLAN Basic Settings**

- If the security type is set to WEP, wireless network adapters that only operate in 802.11n mode may not be able to access the device.

**WiFi Status**  Enabled  Disabled

**Working Band** 2.4GHz

**SSID** DTU\_MD83X\_A42F

**Security Type** WPA2-PSK

**Wi-Fi Password** .....

Show Password

**SSID Broadcast**  Enabled  Disabled

Note: If the SSID broadcast is turned off, the customer must enter the correct SSID to connect to the WLAN. For more information, please refer to the help.

**AP Isolate Switch** Disabled

OK Cancel

-Wi-Fi Status: Enabled / Disabled

-SSID: Any Name

-Security Type: Any Security Type

-Wi-Fi Password: Any Wi-Fi

Password-SSID Broadcast: Enabled (If you want to publish the SSID) / Disabled (if you do not want to expose the SSID)

- AP Isolate Switch: Disabled (do not block communication between wireless clients) / Enabled (block communication between wireless clients)

4. Select [OK].

### 3. Wireless MAC Filter

1. Log in to the WebUI and select [Wireless] from the main menu.
2. Select [Wireless MAC Filter] from the side menu.
3. Select the following mode from MAC Filtering Mode, and then select [Save].
  - Disable: To disable
  - Allow: Specify the MAC address of the device to be allowed
  - Deny: Specify the MAC address of the device that is not allowed
4. Select the [Add] button.
5. On the Add MAC Filter Address screen, enter the MAC address of the device and select [Save].

**Add MAC Filter Address** X

·  ·  ·  ·  ·

---


**Save**

# 9. VPN


This chapter describes the procedure for setting up a VPN.

## 1. SSTP

1. Log in to the WebUI and select [System] from the main menu.
2. Select SSTP from the Protocol pull-down menu.



3. Select SSTP from the Protocol pull-down menu.
4. Set the following:



-Server: VPN server address to connect to


-Root Cert: Set the certificate of the VPN you want to connect to, and press [Load].

-Type:

- Password: Password method
- Certificates(TLS): Certificate method

-Enter the PAP/CHAP Username: (password method) username

- Enter the PAP/CHAP Password: (password method) password
  - User certificate :(certificate method) Set the certificate and press [Load].
  - User private key: (Certificate method) Select Private Key and press [Load].
5. Click the [Save] button.
  6. When the VPN Connection Status becomes Connected, the connection is complete.
  7. Select [Dashboard] from the menu of WebUI.
  8. The VPN information is displayed in the VPN section.



## 2. IPSec

1. Log in to the WebUI and select [System] from the main menu.
2. Select the IPSec Tunnel menu.
3. Set the following:

The screenshot shows the 'IPSec Tunnel' configuration page. The top navigation bar includes 'IoT', 'Dashboard', 'Internet', 'Wireless', and 'System'. The left sidebar lists 'Firmware Upgrade', 'System Settings', 'VPN', 'IPSec Tunnel' (selected), 'OpenVPN', 'Advance Settings', and 'WAN Port PING'. The main configuration area includes:

- IPSec Switch:** Enabled (dropdown)
- IPSec Connection Status:** Disconnected
- IPSec Mode:** Tunnel (dropdown)
- Remote Address:** 0.0.0.0
- DPD Delay(sec):** 30
- Key Exchange Mode:** ikev2 (dropdown)
- Local Subnets:** 0.0.0.0/0
- Remote Subnets:** 0.0.0.0/0
- Phase #1:** Lifetime: 3600
- Phase #2:** Lifetime: 3600
- IKE Encryption:** aes128 (dropdown)
- ESP Encryption:** aes128 (dropdown)
- IKE Hash:** sha1 (dropdown)
- ESP Hash:** sha1 (dropdown)
- DH Group:** modp1024 (dropdown)
- PFS Group:** none (dropdown)
- Authentication Method:** psk (dropdown)
- Pre-Shared Key:** \*\*\*\* (password field with 'Show Password' checkbox)

A 'Save' button is located at the bottom right of the configuration area.

-IPSec Switch: Enabled/Disabled VPN server address

-IPSec Connection Status - Displays the status of the connection with the IPSec server

-IPSec Mode: Select from Tunnel/Transport

-Remote Address: Enter the address of the IPSec server.

-DPD Delay (sec): DPD (Dead Peer Detection), IPsec tunnel communication interruption in real time

Set the time period to be detected (same effect as Heartbeat)



- Key Exchange Mode: Select from ikev1 / ikev2
- Local Subnets: Enter the addresses of local subnets protected by IPsec
- Remote Subnets: Enter the addresses of remote subnets protected by IPsec

Phase # 1 (Security Association Phase1)

- Lifetime: Enter the survivable time of Phase 1
- IKE Encryption: Select encryption algorithm from aes128 / aes192 / aes256 / 3des
- IKE Hash: Select authentication algorithm from sha1 / sha256 / sha384 / sha512 / md5
- DH Group: Select DH Group.

Phase # 2 (Security Association Phase2)

- Lifetime: Enter the survivable time of Phase 2
- ESP Encryption: Select encryption algorithm from aes128 / aes192 / aes256 / 3des
- ESP Hash: Select authentication algorithm from sha1 / sha256 / sha384 / sha512 / md5
- PFS Group: Select PFS Group.

- Authentication Method: Authentication method, fixed by psk (Pre-shared Key)
- Enter the Pre-Shared Key: psk password

4. Click the [Save] button.
5. When the IPsec Connection Status becomes Connected, the connection is complete.

# 10. RS485/232

This chapter describes the procedures related to RS485/232.

## 1. Modbus RTU connection

1. Connect the target device to this product via RS485 and RS232.
2. Log in to the WebUI and select [IoT] from the main menu.
3. Select [RS485/232] from the menu.
4. Use Modbus Setting to set the communication according to the target device.

IoT > RS485/232

Modbus Setting | Modbus List | Profile List

CSV Convert: Start Stop

### Modbus Setting

- \* Switch: Enabled
- \* CRC: Enabled
- \* Mode: Master
- \* Parity: NONE
- \* Serial type: RS485
- \* Baud rate: 9600
- \* Data Bits: 8
- \* Stop Bits: 1
- \* Acquisition Cycle: 1min
- \* Timeout: 50 ms

Save

- CSV Convert Select: Stop/Start (leave it as Stop in the procedure)
- Switch: Enabled/Select Disabled (Select Enabled when using RTU)
- CRC: Enabled/Select Disabled (If you want to use CRC, select Enabled.)
- Mode: Master fixed (cannot be changed / Slave will be supported in the future)
- Parity: Select according to the settings of the target device
- Serial Type: RS485/Select RS232
- Baud rate: Select according to the settings of the target device

- Stop Bits: Select according to the settings of the target device
- Acquisition Cycle: Select the data acquisition interval
- Timeout: maximum acquisition time

5. Press the [Seve] button.

## 2. Connectivity Device Settings (Pre-installed Devices)

### 2-1. Pre-installed device settings

1. Select [Modbus List] from the menu.
2. Click [Add].
3. Register the target device.

-Name: Enter the name

-Salve Id: Enter the slave ID of the target device.

-Profile: Specify the profile of the target device (Default if there is none)

4.[ Click OK.

### 2-2. List of Pre-installed Devices

By selecting a pre-installed device, you do not need to set up details.

| brand | name               | Model No.       |
|-------|--------------------|-----------------|
| OMRON | Power Usage Logger | Model KM-N1-FLK |

### 2-3. Check data of pre-installed devices

For pre-installed devices, you can check the values on the WebUI.

1. Select [Profile List] from the menu.
2. Select the target device from Select Profile.
3. It is possible to check the acquired data.

### 2-4.CSV output for pre-installed devices

For pre-installed devices, CSV output of acquired data is possible.

1. After the settings of the pre-installed device are completed
2. Select [Modbus Setting] from the menu.
3. Select Start from CSV Convert
4. Click [OK].
5. CSV output is completed.

IoT > RS485/232

Modbus Setting | Modbus List | Profile List

CSV Convert: Start Stop

### Modbus Setting

- \* Switch:
- \* CRC:
- \* Mode:
- \* Parity:
- \* Serial type:
- \* Baud rate:
- \* Data Bits:
- \* Stop Bits:
- \* Acquisition Cycle:
- \* Timeout:  ms

Save

### 3.Connectivity Device Settings (Non Pre-installed Devices)

For devices that not in pre-installed devices list, please do settings manually.

1. Click on the Slave Id link

IoT > RS485/232

Modbus Setting | **Modbus List** | Profile List

#### List of Slaves

Add

| No. | Name | Slave Id | Profile   | Operation                                |
|-----|------|----------|-----------|------------------------------------------|
| 1   | N1   | 1        | KM-N1-FLK | <a href="#">Edit</a> <a href="#">Del</a> |

#### List of Variable

Slave Id: 1 Add

| No. | Name | Start Address | Register/Bits | Read/Write | Value | Response | Operation |
|-----|------|---------------|---------------|------------|-------|----------|-----------|
|-----|------|---------------|---------------|------------|-------|----------|-----------|

2. Click the [Add] button from the List of Variable screen on the right.

### 3. Configure the settings from Add Variable window.

- Name of Variable: Enter the name
- Unit: Enter the unit
- Function Code: Select function code
- Start Address (Hexadecimal): Enter the start address
- Number of Bits: Number of bits
- Read/Write: Select only Read or only Write

### 4. Click [OK].

IoT > Modbus-RTU

Modbus Setting | **Modbus List** | Profile List

#### List of Slaves

[Add](#)

| No. | Name | Slave Id | Profile | Operation                                |
|-----|------|----------|---------|------------------------------------------|
| 1   | test | 1        | default | <a href="#">Edit</a> <a href="#">Del</a> |

#### List of Variable

Slave Id: 1 [Add](#)

| No. | Name  | Start Address | Register/Bits | Read/Write | Value | Response | Operation                                |
|-----|-------|---------------|---------------|------------|-------|----------|------------------------------------------|
| 1   | test  | 0001          | 1             | Only read  | 0.01  | -        | <a href="#">Edit</a> <a href="#">Del</a> |
| 2   | test2 | 0002          | 1             | Only write | 0000  | writing  | <a href="#">Edit</a> <a href="#">Del</a> |

The acquired data is displayed in the Value field.

# 11. EnOcean

This chapter describes the procedures related to EnOcean.

## 1. EnOcean Device Manager screen description

1. Log in to the WebUI and select [IoT] from the main menu.
2. Select [EnOcean] from the menu.

IoT > EnOcean

EnOcean Device Manager EnOcean Equipment

EnOcean Device Manager

Source of Data  Internal  External

**Registered Devices** *List of registered devices* Manually Register Device

| Device Name          | Device ID | EEP      | EEP function        | EEP Type                                            | Data        | RSSI | Operation  |
|----------------------|-----------|----------|---------------------|-----------------------------------------------------|-------------|------|------------|
| <a href="#">test</a> | 05005B76  | A5-02-30 | Temperature Sensors | 10 Bit Temperature Sensor Range<br>-40°C to +62.3°C | 93 FA 55 0A | -58  | UnRegister |

**Unregistered Devices** *List of unregistered devices receiving*  Show Only Teach Packets Clear Unregistered Devices

| Device ID | Packet Type    | Telegram Type | EEP     | EEP function | EEP Type | Data                          | RSSI | Teach Data | Operation |
|-----------|----------------|---------------|---------|--------------|----------|-------------------------------|------|------------|-----------|
| 0502DB21  | Packet Type 10 | 4BS           | Unknown | Unknown      | Unknown  | 82 45 87 0E                   | -60  | -          | Register  |
| 04144135  | Packet Type 10 | VLD           | Unknown | Unknown      | Unknown  | A8 22 C0 00 03<br>DB 1B 26 A0 | -68  | -          | Register  |

### 3. Select Source of Data

- Internal: When receiving a sensor with EnOcean built-in this product (normal use)
- External: When using USB400J receiver

### 4. Check the screen display

Registered Devices: Registered sensors are displayed

Unregistered Device: Automatically searched sensors are displayed.

## 2. Register from the Unregistered Device list

\* Register sensors from the auto searched sensor list

1. Click [Register] for the sensor you want to register with this product from the Unregistered Devices list.

**Unregistered Devices**  Show Only Teach Packets Clear Unregistered Devices

| Device ID | Packet Type    | Telegram Type | EEP     | EEP function | EEP Type | Data                          | RSSI | Teach Data | Operation |
|-----------|----------------|---------------|---------|--------------|----------|-------------------------------|------|------------|-----------|
| 0502DB21  | Packet Type 10 | 4BS           | Unknown | Unknown      | Unknown  | 7C 45 86 0E                   | -52  | -          | Register  |
| 04144135  | Packet Type 10 | VLD           | Unknown | Unknown      | Unknown  | A7 21 80 00 03<br>DB 1A A6 E0 | -68  | -          | Register  |

2. Enter the information into New EnOcean Devices window.

**New EnOcean Devices** X

EnOcean Device Name

EnOcean Device id

EnOcean RORG

EnOcean Function

EnOcean Type

OK Cancel

- EnOcean Device Name: Enter a name of your choice (up to 16 characters, alphanumeric)
- EnOcean Device id: Corresponding sensor ID (no need to change)
- EnOcean RORG: Select EEP-RORG of the corresponding sensor
- EnOcean Function: Select the EEP-Function of the corresponding sensor
- EnOcean Type: Select the EEP-Type of the corresponding sensor.

3. Click the [OK] button.
4. Sensor registered into Registered Devices list.

### 3. Register from Manually Register Device

\* Register sensors those are not auto searched

1. Click the [Manually Register Device] button.



2. Enter the information into New EnOcean Devices window.

The screenshot shows a dialog box titled 'New EnOcean Devices' with a close button (X) in the top right corner. The dialog contains the following fields:

- EnOcean Device Name: An empty text input field.
- EnOcean Device id: A text input field containing the value '04144135'.
- EnOcean RORG: A dropdown menu with 'USR DEFINE' selected.
- EnOcean Function: A dropdown menu with 'USR DEFINE' selected.
- EnOcean Type: A dropdown menu with 'USR DEFINE' selected.

At the bottom of the dialog, there are two buttons: 'OK' and 'Cancel'.

- EnOcean Device Name: Enter a name of your choice (up to 16 characters, alphanumeric)
- EnOcean Device id: Enter the corresponding sensor ID
- EnOcean RORG: Select the EEP-RORG of the corresponding sensor
- EnOcean Function: Select the EEP-Function of the corresponding sensor
- EnOcean Type: Select the EEP-Type of the corresponding sensor

3. Click the [OK] button.

4. Sensor registered into Registered Devices list.



#### 4. Register through Teach-in

\*Get your Teach-in information and register

1. Press the LEARN button of the corresponding sensor.
2. When you receive the Teach Data, click [Register].

**Unregistered Devices**  Show Only Teach Packets Clear Unregistered Devices

| Device ID | Packet Type    | Telegram Type | EEP      | EEP function           | EEP Type                                                                     | Data                                | RSSI | Teach Data                 | Operation             |
|-----------|----------------|---------------|----------|------------------------|------------------------------------------------------------------------------|-------------------------------------|------|----------------------------|-----------------------|
| 04144135  | Packet Type 10 | VLD           | D2-14-41 | Multi Function Sensors | Indoor -Temperature,<br>Humidity XYZ<br>Acceleration, Illumination<br>Sensor | 9B D3 C0 00<br>2B EA FA D7<br>40 B0 | -61  | 40 FF 0B 00 41<br>14 D2 C4 | <span>Register</span> |

3. Enter the information into New EnOcean Devices window.

**New EnOcean Devices** X

EnOcean Device Name

EnOcean Device id

EnOcean RORG

EnOcean Function

EnOcean Type

OK Cancel

- EnOcean Device Name: Enter a name of your choice (up to 16 characters, alphanumeric)
- EnOcean Device id: Corresponding sensor ID (no need to change)
- EnOcean RORG: EEP-RORG of the corresponding sensor (no change required)
- EnOcean Function: EEP-Function of the corresponding sensor (no change required)
- EnOcean Type: EEP-Type of the corresponding sensor (no change required)

4. Click the OK button.
5. Sensor registered into Registered Devices list.

## 5. EnOcean Equipment Screen Description


The sensor registered here will be the data sent to Cloud or Modbus TCP.

1. Log in to the WebUI and select [IoT] from the main menu.
2. Select [EnOcean] from the menu.
3. Click [EnOcean Equipment] from the menu.

IoT > EnOcean

EnOcean Device Manager EnOcean Equipment

### EnOcean Equipment

01 Name test  -

temperature: 24.0°C

humidity: 33.0%

illumination: 15lx


accelerationStatus: threshold1


accelerationX: -0.005g


accelerationY: 0.025g

accelerationZ: 1.005g

contact: open


02 Name  +


03 Name  +

04 Name  +

## 6. Add registered sensor into EnOcean Equipment List

1. Press the [gear icon] on the right side of the number 01.
2. Select the sensor you want to add into EnOcean Equipment List from registered sensors.


EnOcean Equipment Configuration 

Input Device test 

OK Cancel

3. Click [OK].

4.01 If you press [+] on the right side, you can check the details of the value received from the sensor.




## 7. Delete registered sensor

1. Click the [Trash can icon] on the right side of EnOcean Equipment page.



2. Click [UnRegister] on the right side of the EnOcean Device Manager page.



3. The registered sensor is deleted.

## 8. List of supported EEPs

\*List of EEPs that can be decoded

| ROR G | ROR G | FUN C | FUNC NAME                               | TYP E | TYPE NAME                                                                 | EEP Number |
|-------|-------|-------|-----------------------------------------|-------|---------------------------------------------------------------------------|------------|
| F6    | RPS   | 02    | Rocker Switch, 2 Rocker                 | 04    | Light and blind control ERP2                                              | F60204     |
| D5    | 1BS   | 00    | Contacts and Switches                   | 01    | Single Input Contact                                                      | D50001     |
| A5    | 4BS   | 02    | Temperature Sensors                     | 05    | Temperature Sensor Range 0° C to +40° C                                   | A50205     |
| A5    | 4BS   | 02    | Temperature Sensors                     | 14    | Temperature Sensor Range -20° C to +60° C                                 | A50214     |
| A5    | 4BS   | 02    | Temperature Sensors                     | 17    | Temperature Sensor Range +10° C to +90° C                                 | A50217     |
| A5    | 4BS   | 02    | Temperature Sensors                     | 30    | 10 Bit Temperature Sensor Range -40° C to +62.3° C                        | A50230     |
| A5    | 4BS   | 04    | Temperature and Humidity Sensor         | 01    | Range 0° C to +40° C and 0% to 100%                                       | A50401     |
| A5    | 4BS   | 04    | Temperature and Humidity Sensor         | 02    | Range -20° C to +60° C and 0% to 100%                                     | A50402     |
| A5    | 4BS   | 04    | Temperature and Humidity Sensor         | 03    | Range -20° C to +60° C 10bit-measurement and 0% to 100%                   | A50403     |
| A5    | 4BS   | 06    | Light Sensor                            | 01    | Range 300lx to 60.000lx                                                   | A50601     |
| A5    | 4BS   | 06    | Light Sensor                            | 02    | Range 0lx to 1.020lx                                                      | A50602     |
| A5    | 4BS   | 06    | Light Sensor                            | 03    | 10-bit measurement (1-Lux resolution) with range 0lx to 1000lx            | A50603     |
| A5    | 4BS   | 07    | Occupancy Sensor                        | 01    | Occupancy with Supply voltage monitor                                     | A50701     |
| A5    | 4BS   | 07    | Occupancy Sensor                        | 02    | Occupancy with Supply voltage monitor                                     | A50702     |
| A5    | 4BS   | 07    | Occupancy Sensor                        | 03    | Occupancy with Supply voltage monitor and 10-bit illumination measurement | A50703     |
| A5    | 4BS   | 08    | Light, Temperature and Occupancy Sensor | 01    | Range 0lx to 510lx, 0° C to +51° C and Occupancy Button                   | A50801     |
| A5    | 4BS   | 08    | Light, Temperature and Occupancy Sensor | 02    | Range 0lx to 1020lx, 0° C to +51° C and Occupancy Button                  | A50802     |

|    |     |    |                                         |    |                                                                                      |        |
|----|-----|----|-----------------------------------------|----|--------------------------------------------------------------------------------------|--------|
| A5 | 4BS | 08 | Light, Temperature and Occupancy Sensor | 03 | Range 0lx to 1530lx, -30° C to +50° C and Occupancy Button                           | A50803 |
| A5 | 4BS | 09 | Gas Sensor                              | 04 | CO2 Sensor                                                                           | A50904 |
| A5 | 4BS | 10 | Room Operating Panel                    | 01 | Temperature Sensor, Set Point, Fan Speed and Occupancy Control                       | A51001 |
| A5 | 4BS | 10 | Room Operating Panel                    | 03 | Temperature Sensor, Set Point Control                                                | A51003 |
| A5 | 4BS | 10 | Room Operating Panel                    | 04 | Temperature Sensor, Set Point and Fan Speed Control                                  | A51004 |
| A5 | 4BS | 10 | Room Operating Panel                    | 05 | Temperature Sensor, Set Point and Occupancy Control                                  | A51005 |
| A5 | 4BS | 10 | Room Operating Panel                    | 07 | Temperature Sensor, Fan Speed Control                                                | A51007 |
| A5 | 4BS | 10 | Room Operating Panel                    | 08 | Temperature Sensor, Fan Speed and Occupancy Control                                  | A51008 |
| A5 | 4BS | 10 | Room Operating Panel                    | 0C | Temperature Sensor and Occupancy Control                                             | A5100C |
| A5 | 4BS | 10 | Room Operating Panel                    | 10 | Temperature and Humidity Sensor, Set Point and Occupancy Control                     | A51010 |
| A5 | 4BS | 10 | Room Operating Panel                    | 12 | Temperature and Humidity Sensor and Set Point                                        | A51012 |
| A5 | 4BS | 10 | Room Operating Panel                    | 13 | Temperature and Humidity Sensor, Occupancy Control                                   | A51013 |
| A5 | 4BS | 10 | Room Operating Panel                    | 19 | Humidity, Temperature Set Point, Temperature Sensor, Fan Speed and Occupancy Control | A51019 |
| A5 | 4BS | 14 | Multi-Func Sensor                       | 05 | Vibration/Tilt, Supply voltage monitor                                               | A51405 |
| A5 | 4BS | 30 | Digital Input                           | 02 | Single Input Contact                                                                 | A53002 |
| A5 | 4BS | 30 | Digital Input                           | 05 | Single Input Contact, Retransmission, Battery Monitor                                | A53005 |
| D2 | VLD | 14 | Multi Function Sensors                  | 40 | Indoor -Temperature, Humidity XYZ Acceleration, Illumination Sensor                  | D21440 |
| D2 | VLD | 14 | Multi Function Sensors                  | 41 | Indoor -Temperature, Humidity XYZ Acceleration, Illumination Sensor                  | D21441 |

## 9. List of Supported GPs

\*List of GPs that can be decoded

| Maker      | Sensor Type                                                | GP Number   |
|------------|------------------------------------------------------------|-------------|
| Watty Inc. | 2Wireless temperature sensor                               | HYHQ        |
|            | 4 Wireless Temperature Sensors                             | HYHQ-FF     |
|            | Electronic Wet Bulb Black Bulb Temperature Wireless Sensor | WBGT_7500_E |

# 12. Modbus TCP

This chapter describes the procedures related to Modbus TCP.

## 1. Modbus TCP connection

1. Log in to the WebUI and select [IoT] from the main menu.
2. Select [Modbus TCP] from the menu.
3. Enter the following from [Modbus TCP Setting].

IoT > Modbus TCP

Modbus TCP Setting | Address Mapping List

### Modbus TCP Setting

Data Source:  ▼

Modbus TCP Switch:  ▼

Host Mode:  ▼

Host Address:

\* Port:

-Data Source:

EnOcean / Modbus RTU

-Modbus TCP Switch: Enabled (to enable) / Disabled (to disable)

-Host Mode / Host Address

LAN(Gateway) / default gateway address

LAN(Static) / Ethernet static address

WAN(LTE) / cellular address

WAN (Wi-fi STA) / Wi-fi allocated address

WAN(DHCP/Static) / wired WAN address

-Port: 1502~1562

4. Select Save.

## 2. Modbus Address Map (EnOcean)

\*When EnOcean is selected as data source

1. Log in to the WebUI and select [IoT] from the main menu.
2. Select [Modbus TCP] from the menu.
3. Select Address Mapping List.

| Data Source | Address     | Data        | Equipment No | Channel | R/W |
|-------------|-------------|-------------|--------------|---------|-----|
| EnOcean     | 30001~30959 | 32bit float | 1~24         | 1~20    | R   |

4. Check the address map on the WebUI and make a request to the address specified by this product from the Modbus tool or server
  - . Example) Humidity data can be obtained by requesting TCP Address 30003.

IoT > Modbus TCP

Modbus TCP Setting    Address Mapping List

### Address Mapping List

Toggle Sequence Nnumber:

| Channel | Tag   | Address | Data Type | Data   |
|---------|-------|---------|-----------|--------|
| 0       | TMP10 | 30001   | 32b_float | 25.500 |
| 1       | NA    | 30002   | NA        | 0.000  |
| 2       | HUM   | 30003   | 32b_float | 67.500 |
| 3       | NA    | 30004   | NA        | 0.000  |
| 4       | ILL   | 30005   | 32b_float | 0.000  |

## 3. Modbus Address Map (Modbus RTU)

\*If Modbus RTU is selected in the data source

1. Log in to the WebUI and select [IoT] from the main menu.
2. Select [Modbus TCP] from the menu.
3. Select Address Mapping List.

| Data Source | Address     | Data        | R/W |
|-------------|-------------|-------------|-----|
| Modbus RTU  | 30001~31000 | 16bit float | R   |

4. Click the [Add] button.



### Add Mapping X

|                     |             |
|---------------------|-------------|
| Modbus RTU Slave ID | 1 : N1      |
| Modbus TCP Address  | 30001~31000 |
| Modbus RTU Address  | 0200        |
| Data Type           | 16B_Float   |

Save
Cancel

\*Modbus RTU equipment must be set up in advance.

4. Select the following

- Modbus RTU Slave ID: Modbus RTU Select the device set in
- Modbus TCP Address: Modbus TCP Select from address 30001~31000
- Modbus RTU Address: Select the address map of the device connected to Modbus RTU.
- Data Type: Select the data type

5. Click the [Save] button.

6. Check the address map on the WebUI and make a request to the address specified by the product from the Modbus tool or server.

Example) If you request TCP Address30001, you can get RTU Address0200 data.

IoT > Modbus TCP

Modbus TCP Setting
Address Mapping List

### Address Mapping List

Add

| Modbus RTU Slave ID | Modbus TCP Address | Modbus RTU Address | Data Type | Data     | Operation                                |
|---------------------|--------------------|--------------------|-----------|----------|------------------------------------------|
| 1                   | 30001              | 0200               | 16b_float | 1040.000 | <a href="#">Edit</a> <a href="#">Del</a> |

# 13. FTP/SFTP

This chapter describes FTP/SFTP-related procedures.

## 1. FTP Upload

- \* Upload CSV file converted from RS485/232.
- \* Compatible devices: OMRON's KM-N1-FLK

1. Log in to the WebUI and select [IoT] from the main menu.
2. Select [FTP/SFTP] from the menu.
3. Select [FTP Upload].
4. Configure the following settings.

IoT > FTP/SFTP

FTP Upload | FTP Gather | Un\_upload List

### FTP Upload

Enable This Connection:

Type: FTP

\* Server:

\* Port: 21

Mode: PORT Mode

\* User Name:

\* Password:

\* Interval Time:  s

File Prefix:

OK

- Enable This Connection: Check if you want to use it.
- Type: Select FTP/SFTP
- Server: Enter the IP address of the upload destination.
- Port: Fixed value by selecting Type (no change required)
- User Name: Enter the user name of the upload destination
- Password: Enter the password of the upload destination
- Interval Time: Set the upload interval

-File Prefix: Name of the output folder (initial)

5. Click OK.

## 2. FTP Gather

\* Ability to retrieve files from subordinate devices.

\*Compatible devices: OMRON's KM-D1-ETN

1. Log in to the WebUI and select [IoT] from the main menu.

2. Select [FTP/SFTP] from the menu.

3. Select [FTP Gather].

4. Configure the following settings.

IoT > FTP/SFTP

FTP Upload FTP Gather

### FTP Gather

Enable Gather Func:

Server: 192.168.1.222

Port: 21

User Name: ftp

Password: \*\*\*

Dev-Type: KM-D1-ETN

Method: Manual

Date-range: 2023-06-06 to 2023-06-07

DownLoad OK

-Enable This Connection: Check if you want to use it.

-Server: Enter the IP address of the subordinate, device.

-Port: Specify the port

-User Name: User name of the subordinate device

-Password: Password name of the subordinate device

• Dev-Type: KM-D1-ETN (cannot be changed / other devices will be supported)

• Method: Manual/Auto

-Data-range: Target period of the CSV you want to obtain


5. Click [Download]

6. CSV for the target period is saved in the product.


### 3. Un\_upload List

\* Function to check the list of CSV files saved in this product.

1. Log in to the WebUI and select [IoT] from the main menu.
2. Select [FTP/SFTP] from the menu.
3. Select [Un\_upload List].



4. Select a folder for the date.



- \* CSV files are saved by creating folders for each date.
- \* Files that have been successfully uploaded will be deleted.
- \* CSV files are stored for up to 7 days and deleted in folders at 23:59 on the 7th day.

# 14. MQTT

This chapter describes the procedures related to MQTT.

1. Log in to the WebUI and select [IoT] from the main menu.
2. Select [MQTT] from the menu.

| Index | Enable   | Name | Client id | Host | Port | Connection status | Start/Stop |
|-------|----------|------|-----------|------|------|-------------------|------------|
| 1     | Disabled | -    | -         | -    | -    | -                 | -          |
| 2     | Disabled | -    | -         | -    | -    | -                 | -          |
| 3     | Disabled | -    | -         | -    | -    | -                 | -          |
| 4     | Disabled | -    | -         | -    | -    | -                 | -          |

3. Select any number in the index.  
\*4 MQTTs can be used at the same time
4. Select any number in the index.

**MQTT List**

| Index | Enable   | Name | Client id | Host | Port | Connection status | Start/Stop |
|-------|----------|------|-----------|------|------|-------------------|------------|
| 1     | Disabled | -    | -         | -    | -    | -                 | -          |
| 2     | Disabled | -    | -         | -    | -    | -                 | -          |
| 3     | Disabled | -    | -         | -    | -    | -                 | -          |
| 4     | Disabled | -    | -         | -    | -    | -                 | -          |

**General Settings**

Index:

Enable:

Save

-Enabled: Enabled (if enabled)/Disable (If you want to disable it)

5. Click the [OK] button.
6. Enter the following:

### General Settings

|             |                                                |
|-------------|------------------------------------------------|
| Index       | <input type="text" value="1"/>                 |
| Enable      | <input type="text" value="Enabled"/>           |
| * Name      | <input type="text" value="zf1"/>               |
| * Client id | <input type="text" value="1"/>                 |
| * Host      | <input type="text" value="broker.hivemq.com"/> |
| * Port      | <input type="text" value="8883"/>              |
| User name   | <input type="text"/>                           |
| Password    | <input type="password"/>                       |

- Name: Arbitrary name
- Client id: Any ID
- Host: Destination host address
- Port: PORT number (MQTT:1883/MQTTS:8883)

7. If you are using MQTTS, set TLS to Enabled and select a certificate.

|              |                                                                                                     |
|--------------|-----------------------------------------------------------------------------------------------------|
| TLS          | <input type="text" value="Enabled"/>                                                                |
| * CA File:   | <input type="text" value="ssl_cafile.pem"/> <input type="button" value="Load"/> Upload successful   |
| Cert File:   | <input type="text" value="ssl_certfile.pem"/> <input type="button" value="Load"/> Upload successful |
| Key File:    | <input type="text" value="ssl_keyfile.pem"/> <input type="button" value="Load"/> Upload successful  |
| * Timeout    | <input type="text" value="10"/> s                                                                   |
| * Keep alive | <input type="text" value="60"/> s                                                                   |
| Version      | <input type="text" value="V5.0"/>                                                                   |
| LWT Topic    | <input type="text"/>                                                                                |
| LWT Qos      | <input type="text" value="1"/>                                                                      |
| LWT Retain   | <input type="text" value="Disabled"/>                                                               |
| LWT Payload  | <input type="text"/>                                                                                |

8. Click the [Save] button.

9. Verified that the Connection status is "Connected".

IoT > MQTT

### MQTT List

| Index | Enable   | Name | Client id | Host           | Port | Connection status | Start/Stop |
|-------|----------|------|-----------|----------------|------|-------------------|------------|
| 1     | Enabled  | test | test      | 54.165.198.210 | 1883 | Connected         | Stop       |
| 2     | Disabled | -    | -         | -              | -    | -                 | -          |
| 3     | Disabled | -    | -         | -              | -    | -                 | -          |
| 4     | Disabled | -    | -         | -              | -    | -                 | -          |

10. Configure the data source and publishing.

Data Collection:

Pub Data:  Data Payload  Serial  EnOcean

Data Format:  JSON

Pub Topic:

Pub Qos:

Pub Retain:

Pub Type:  Processed Data  Raw Data

Pub Mode:

Pub Interval:  s

[Save](#)

-Data Collection : Enabled/Disable

-Pub Data : Data Payload (for verification) / Serial / EnOcean:

-Data Format : JSON

-Pub Topic: Enter the topic name

-Pub QoS: Select the message assurance level.

-Pub Retain: Enabled for the Retain function/Select Disable.

-Pub Type :

-Processed Data: Telegram parsed data

-Row Data: Unparsed Telegram data

-Pub Mode :

-Periodic reporting: Time interval report

-Real-time reporting: Real time reporting latest data from sensors

-Pub Interval: Enter the transmission interval (Input is available only when Periodic reporting is selected.)

11. Click the [Save] button.

# 15. Cloud Service

This chapter describes Cloud-related procedures.

## 1. Connect to AWS

1. Log in to the WebUI and select [IoT] from the main menu.
2. Click [AWS] from the menu.
3. Enter the following:

IoT > AWS

### AWS

Connection status: **Connected**

Enable:

\* Source of data:  Serial  EnOcean

\* Data Format:  Json

\* Host:

\* Port Number:

User Name:

Password:

\* CA File:

\* Cert File:

\* Key File:

Reporting method:

\* Topic:

\* EnOcean Data mode:  Processed Data  Raw Data

Additional Json Message:

OK

- Source of data: Select the data sent from EnOcean / Serial.
- Data Format: JSON
- Enable This Connection: Check to start a connection to AWS.
- Host: Enter the AWS endpoint.
- Port Number:8883



- CA File: Select the certificate and press [Load]
- Cert File: Select the certificate file and press [Load]
- Key File: Select the private key file and press [Load]
- Reporting method: Select the communication timing from the following.
  - Periodic reporting: Time interval report
  - Real-time reporting: Real time reporting latest data from sensors
- Interval Time: Enter the transmission interval (can only be entered if Periodic reporting is selected)
- Topic: Enter the topic name of the MQTT
- EnOcean Data Mode:
  - Processed Data: Telegram parsed data
  - Row Data: Unparsed Telegram data
- Additional Json Message : Enter if there is a sentence you want to add to the JSON.
  - \*Example)"reciever\_type" : "500J",
  - \*Please enter according to JSON format.

4. Click [OK].

## 2. Connect to Azure

1. Log in to the WebUI and select [IoT] from the main menu.
2. Click [AWS] from the menu.
3. Enter the following:

The screenshot shows the 'IoT > Azure' configuration page. The 'Connection status' is 'Disconnected'. The 'Enable' dropdown is set to 'Enabled'. Under 'Source of data', 'EnOcean' is selected. Under 'Data Format', 'Json' is selected. There are input fields for 'Host Name', 'Device ID', and 'Shared Access Key'. The 'Reporting method' dropdown is set to 'Periodic reporting'. There is an input field for 'Interval Time' with a 's' unit indicator. Under 'EnOcean Data mode', 'Processed Data' is selected. There is a text area for 'Additional Json Message'. An 'OK' button is located at the bottom right of the form.


- Enable This Connection: Check to start a connection to Azure.
- Host Name:  
Enter your Azure host name - Enter your Device ID: Device ID
- Shared Access Key: Set the access key
- Reporting method: Select the communication timing from the following.
  - Periodic reporting: Time interval report
  - Real-time reporting: Real time reporting latest data from sensors
- Interval Time: Enter the transmission interval (can only be entered if Periodic reporting is selected)
- Topic: Enter the topic name of the MQTT
- EnOcean Data Mode:
  - Processed Data: Telegram parsed data
  - Row Data: Unparsed Telegram data
- Additional Json Message : Enter if there is a sentence you want to add to the JSON.
  - \*Example)"receiver\_type" : "500J",
  - \*Please enter according to JSON format.

4. Click [OK].

# 16. Software Updates

This chapter describes the procedure for updating the software.

1. Log in to the WebUI and select [System] from the main menu.
2. Select [Firmware Upgrade] from the side menu.
3. Select [Browse] and select the update file (~.bin) to be provided separately.
4. Select [Upgrade].




5. A progress bar pop-up is displayed, and the application restarts when the progress reaches 100%.
6. The update is complete.

\* Do not unplug the power during the update.

# 17. Network Interface

This chapter describes the Network Interface.

## Interface Details



Each physical interface operates in one of the roles.

- In the WAN, the FW policy is applied to inbound communication.

LAN (DHCP), wireless LAN, and USB are accepted on the same logical interface.

The WAN interface is registered as the default gateway.

# 18. Revision History

This chapter provides a history of revisions.

The manual revision symbol is appended to the end of the version number on the front cover.

Version Number: NTD83X -User□

↑ Revision symbol

| Revision symbol | Date of revision | Revised page                                                                                                                                                                                                                                                                                                                                                                                            |
|-----------------|------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| A               | December 2022    | first edition                                                                                                                                                                                                                                                                                                                                                                                           |
| B               | January 2023     | Correction of USB description and added about power OFF                                                                                                                                                                                                                                                                                                                                                 |
| C               | March 2023       | Added IoT chapter                                                                                                                                                                                                                                                                                                                                                                                       |
| D               | March 2023       | Added Wireless chapter                                                                                                                                                                                                                                                                                                                                                                                  |
| E               | March 2023       | Corrected the AWS chapter                                                                                                                                                                                                                                                                                                                                                                               |
| F               | March 2023       | Modify the address in the Modbus Address List                                                                                                                                                                                                                                                                                                                                                           |
| G               | April 2023       | Addition of device configuration, product specifications, and TBD items                                                                                                                                                                                                                                                                                                                                 |
| H               | June 2023        | Add Modbus RTU, FTP/SFTP items                                                                                                                                                                                                                                                                                                                                                                          |
| I               | July 2023        | Adding a Wi-Fi STA item                                                                                                                                                                                                                                                                                                                                                                                 |
| J               | September 2023   | Reflect the change in model number<br>Image replacement and procedure change due to WebUI improvement<br>Added Regulatory and Certification items to the Product Specifications chapter<br>Added EEP to EnOcean chapter<br>Modification of RS485/232 chapter, deletion and modification of Modbus Address List<br>Add Azure to the Cloud Service chapter<br>Adding an MQTT Chapter Adding a VPN Chapter |
| K               | October 2023     | Added System Log chapter<br>Modified product specification chapter EnOcean                                                                                                                                                                                                                                                                                                                              |
| L               | October 2023     | Added corresponding EEP to EnOcean chapter                                                                                                                                                                                                                                                                                                                                                              |
| M               | October 2023     | Added MQTTS to the MQTT chapter                                                                                                                                                                                                                                                                                                                                                                         |

|   |               |                                                                                                                |
|---|---------------|----------------------------------------------------------------------------------------------------------------|
| N | October 2023  | Added IPSec to the VPN chapter                                                                                 |
| O | November 2023 | Added Ethernet Management and Network Interface chapters.                                                      |
| P | January 2024  | Removed the System Log chapter, added FTP/SFTP chapter, changed the cover, and changed the information chapter |
| Q | April 2024    | Updated the list of supported EEPs and GPs in the EnOcean chapter.                                             |

## 19. Information

We do not guarantee our products when they are used under conditions or environments not described in this magazine, or when they are used for applications that require particular safety, such as when they are expected to have a significant impact on human life or property, unless there is a special agreement intended by the Company.

Inquiries about products

SyncWave Inc.

E-mail: [info@syncwave.jp](mailto:info@syncwave.jp) / Website: <https://syncwave.jp/>

Version number: NTD83X -UserQ as of April, 2024